Catalog 3900 - Agricultural Quick Coupling Adapters

Pioneer adapters shown here provide the most reliable and exacting interchange in the industry.

How To Connect Using An Adapter

- **Step 1** Relieve trapped pressure in the implement line.
- **Step 2** Connect male tip on the implement line into the adapter.
- Step 3 Connect the Adapter into the female body.

To Disconnect: Reverse the above procedure: first disengage adapter from female body, then male tip from adapter.



Part Number	Adapts This Style Of Male Tip	To This Female Body
4060-4	Pioneer Style	John Deere Old Style
4065-4	John Deere Old Style	Pioneer Style
4065-4L	John Deere Old Style	John Deere 50 Series Ford/ISO Pioneer 9250
4067-4	John Deere Old Style	International Harvester Old Style
4068-4	John Deere Old Style	J I Case Old Style
4070-4	Pioneer Style	International Harvester Old Style
4075-4	International Harvester Old Style	Pioneer Style
4075-4L	International Harvester Old Style	John Deere 50 Series Ford/ISO Pioneer 9250
4076-4	International Harvester Old Style	John Deere Old Style
4080-4	Pioneer Style	J I Case Old Style
4085-4	J I Case Old Style	Pioneer Style



Catalog 3900 - Agricultural Quick Coupling Adapters

To select the proper Pioneer adapter:

Locate your tractor coupler along the left vertical column. Then locate your implement nipple along the top horizontal column. Now follow these two rows inward until they intersect at the correct adapter. For example: The proper adapter to connect a tractor with a Pioneer coupler to an implement with a J.I. Case nipple would be a 4085-4.

Male Tips Female Bodies	John Deere	Pioneer ISO Tip	International Harvester	JI Case (old)	FE / FEM Series Bobcat, John Deere, Gehl, New Helland
John Deere (old)	NO ADAPTER REQUIRED	4060-4	4076-4	N/A	N/A
John Deere (new)	4065-4L	NO ADAPTER REQUIRED	4075-4L	N/A	N/A
International Harvester (old)	4067-4	4070-4	NO ADAPTER REQUIRED	N/A	N/A
J.I. Case (old)	4068-4	4080-4	N/A	NO ADAPTER REQUIRED	N/A
J.I. Case (new)	4065-4L	NO ADAPTER REQUIRED	4075-4L	N/A	N/A
Pioneer*	4065-4	NO ADAPTER REQUIRED	4075-4	4085-4	EAS-500
FE / FEM Series Bobcat, John Deere, Gehl, New Holland	N/A	SAE-500	N/A	N/A	N/A
Parker/Pioneer 60 Series	N/A	4069-4	N/A	N/A	N/A

^{*} Pioneer Couplers include: 4000, 4200, 6600, 8200, 8450, 9200, and 5000 Series

